


**DESPIECE**



## TABLA DE REFACCIONES

POSICIÓN	REFACCIÓN	FLUX55-253234	FLUX55-303234	FLUX55-403234	FLUX55-503234	FLUX55-603234	FLUX55-753234	FLUX83-603234	FLUX83-753234	FLUX83-1003234	FLUX83-1203234	CÓDIGO	
16	BALERO	✓										R-FLUX55-25-BAL	
			✓										R-FLUX55-30-BAL
				✓	✓								R-FLUX55-40/50-BAL
						✓		✓					R-FLUX55/83-60-BAL
								✓		✓			R-FLUX55/83-75-BAL
											✓	✓	R-FLUX83-120-BAL
4	CUERPO DE BOMBA	✓	✓	✓								R-FLUX55-25-40-CB	
					✓	✓	✓					R-FLUX55-50-75-CB	
									✓	✓	✓	✓	R-FLUX83-60-120-CB
10	IMPULSOR	✓										R-FLUX55-25-IMP	
			✓										R-FLUX55-30-IMP
				✓									R-FLUX55-40-IMP
					✓								R-FLUX55-50-IMP
						✓							R-FLUX55-60-IMP
							✓						R-FLUX55-75-IMP
								✓					R-FLUX83-60-IMP
									✓				R-FLUX83-75-IMP
										✓			R-FLUX83-100-IMP
										✓	R-FLUX83-120-IMP		
5	ORING DE CUERPO DE BOMBA	✓	✓	✓								R-FLUX55-OCB	
					✓	✓	✓	✓	✓	✓	✓	R-FLUX55/83-OCB	
11	SELLO MECANICO	✓										R-FLUX-SELLOM1	
			✓	✓								R-FLUX-SELLOM2	
					✓	✓	✓	✓	✓	✓	✓	R-FLUX55-50/83-SM	

POSICIÓN	REFACCIÓN	FLUX55-253234	FLUX55-303234	FLUX55-403234	FLUX55-503234	FLUX55-603234	FLUX55-753234	FLUX83-603234	FLUX83-753234	FLUX83-1003234	FLUX83-1203234	CÓDIGO	
38	VENTILADOR	✓										R-FLUX55-25-VT	
			✓									R-FLUX55-30-VT	
				✓	✓								R-FLUX55-40-50-VT
						✓		✓					R-FLUX55/83-60-VT
								✓		✓			R-FLUX55/83-75-VT
											✓	✓	R-FLUX83-100120-VT
40	TAPA DE VENTILADOR	✓										R-FLUX55-25-TVT	
			✓									R-FLUX55-30-TVT	
				✓	✓								R-FLUX55-40-50-TVT
						✓		✓					R-FLUX55/83-60-TVT
								✓		✓			R-FLUX55/83-75-TVT
											✓	✓	R-FLUX83-100120TVT
	BRIDA	✓	✓	✓	✓	✓	✓					FLUXKB-DN6X4	
								✓	✓	✓	✓	FLUXKB-DN6X6	
13	PLATO PORTA SELLO	✓										R-FLUX-PPSELLO2	
			✓	✓								R-FLUX55-30-40-PPS	
					✓	✓	✓	✓	✓	✓	✓	R-FLUX55-50/83-PPS	